

[www.porotechnic.com](http://www.porotechnic.com)

Zone de Légrin – Route de Saint-Gilles – 30132 CAISSARGUES

04.66.38.38.20 Télécopie : 04.66.38.38.21

S.A.R.L au capital de 50 000 F – SIRET 393122 882 00011

E-mail : [contact@porotechnic.com](mailto:contact@porotechnic.com)

## INTERNAL TREATMENT SKATES EARTHED UP GOT PISSED

Cross resin POROTRINE 2 components 24 hours after the last coat of antisaltpetre in 2 or 3 coats at 24 h of space or 8 days after cleaning if they do not put no anti-saltpetre (only for ancient treatment).

Never do not wait more from 24 h between every coats of resins.

- Overturn into 1 bucket: n °1 (big bottle) then n °2 (small bottle)

Definitely blend (insist) to acquire a homogeneous white paste (appearance yoghurt).

For the treatment of mechanical cooked lands cross 2 coats (2 kits for 30 m<sup>2</sup>).

- Add 2 litres of water to the 1st coat (1st kit)

- Cross 2nd coat the following day with 2 litres of water (2nd kit).

For the treatment of lands cooked by recovery with not smooth epidermis or cooked lands Spanish manual cross 3 coats (3 kits for 30 m<sup>2</sup>).

- 1st puts to bed dilution in 2.5 litres of water (1st kit)

- 2nd puts to bed dilution in 2 litres of water (2nd kit)

- 3rd puts to bed dilution in 1.5 litres of water. (3<sup>rd</sup>)

The blended product can be kept no more than 4 hours.

In case of division, it is necessary to respect volumes:

- n °1 = 4 volumes (by eg 4 tablespoonfuls)

- n °2 = 1 volume (by eg 1 tablespoonful)

- water = 2 volumes of water by coat. (by eg 10 tablespoonfuls)

At any rate you must acquire a homogeneous white paste absolutely. Afterwards rajout of water, if mixture liquidates present of the lumps to throw and to start again mixture.

Application:

- Go about things by bands by stopping well in the joint, never in the middle of a tile.

- Definitely dip the paintbrush by beginning of the tile in the middle of and leaving towards end.

- Put the product in abundance, not get worried about whitish surplus.

- Work on a length maximum of 2 tiles. Never too much draw the product on a too important length to avoid possible traces of brush.

- Slick (with a roll high specific gravity or in defect in flocked foam) as one goes along without supporting. This operation of smoothing being very important on the smooth tiles (mechanics).

- Definitely rinse in clear water brush and roll after the end of job and let soak in water.

**RESPECT THE QUANTITIES OF PRODUCT**

**For 100 m2 in 2 coats 6 - 8 doses according to porosity of the material**

**So 3rd necessary coat 2 - 3 additional doses**

**THE LENGTH OF THE TREATMENT DEPENDS ON THE RESPECT FOR QUANTITIES.**

Translation by a generator.